

Karta techniczna produktu

Chemmot Ewa Kumorek spółka komandytowa PL 32-050 Skawina, ul. Józefa Piłsudskiego 59 Telefon: 12 276 75 45

Telefax: 12 276 78 20

DECO COLOR® znak towarowy CHEMMOT® DECO COLOR® najlepiej postrzegany brand farb i lakierów w aerozolu

Trade name

FLUOMARKER by DECO COLOR® aerosol line

Article No

14 510; 14 520; 14 530; 14 540; 14 550; 14 560; 14 570; 14 580

Seller/Manufacturer

Chemmot Ewa Kumorek spółka komandytowa; Józefa Piłsudskiego 59, 32-050 Skawina, Polska

Product's description

Professional marker for surveying, construction, and forestry. Perfect for works on surfaces like: asphalt, wood, metal, concrete, glass, stone. Perfect for works directly on the ground even in difficult weather conditions. Application: land and water constructions, building of roads and highways, power lines, pipe lines, water supply systems, archaeology, warehouse works, marking dangerous places of architecture, forestry and cutting down the trees.

Main features

360° nozzle and special valve allows applying in every position (even upside down) Ergonomic head Very good covering Weather condition resistance Offer in 8 most common colours For indoor and outdoor use

Physical and Chemical Properties

Other coating applying not necessary



Karta techniczna produktu

Chemmot Ewa Kumorek spółka komandytowa PL 32-050 Skawina, ul. Józefa Piłsudskiego 59

Telefon: 12 276 75 45 Telefax: 12 276 78 20

DECO COLOR® znak towarowy CHEMMOT® DECO COLOR® najlepiej postrzegany brand farb i lakierów w aerozolu

Usage

When Fluomarker is used to marking, there is no need of primer usage.

Notice: To achieve better result manufacturer recommends to prime surface with white primer previously. For additional protection fluorescent coating should be covered with clear acrylic lacquer by DECO COLOR.

Method of use

Apply product at temperature about 15-25°C (optimum temperature for good varnish drying). Drying time depends also on air humidity and product density.

Painting should be made in well ventilated room.

Prior to commencing painting, shake the container for about one minute, what helps mix the varnish by the ball inside.

Perform the test spray.

Apply the varnish with few thin layers rather than one thick layer, from the distance of 25-30 centimetres.

Wait few minutes between each layer when applying.

Technical Data Sheet version 05 from 01/03/2022